

## SCREWS

Self-tapping screws are available for securing PCBs and mounting plates as well as components.

Installation instructions: Please note the different types of cross-head screws (PZ / PH) as well as the size of the screwdriver.



## Select Versions



A0304031 Self-tapping screws 2.2 x 5 mm (PZ1)



A0305031 Self-tapping screws 2.5 x 6 mm (PZ1)



A0306031 Self-tapping screws 3 x 6 mm (PZ1)



A0308031 Self-tapping screws 3 x 8 mm (PZ1)

## SCREWS





A0308132 Self-tapping screw 3 x 8 mm (T10) Stainless steel



A0325060 Self-tapping screw 2.5 x 6 mm (T8) Stainless steel



A0325080 Self-tapping screws 2.5 x 8 mm (PZ1)



A0330080 Screw M3 x 8 mm (T10) Stainless steel



A9199008 Set of screws



B5111201 Set of screws

Subject to technical modification without notice. © by OKW Gehäusesysteme, Buchen/Germany.